

QUICK REFERENCE GUIDE

12/9/2003



Model	Fuser	Maintenace Kits	Pickup roller	Pickup Assembly	Transfer Roller	Separation Pad	Delivery Assembly	Toner C.
1000	RG9-1493	N/A	RFO-1008	RG0-1085	RG9-1483	RFO-1014	RG0-1010	C7115X
1100	RG5-4589	H3965-6001	RB2-4026	N/A	RG5-4657	RF5-2886 Separation Pad RY7-5050 Sub Pad Kit	RG5-4593	C4092A
1200/1220	RG9-1493	N/A	RFO-1008	RG0-1003	RG9-1483	RFO-1014 RY7-5055 Scanner	RG0-1010	C7115X
2100	RG5-4132	H3974-60001	RB2-2900 Tray 1 RB2-2891 Tray 2/3	RG5-4128 Tray 1 RG5-4127	RG5-4164	RB2-2835 Tray 1 RB2-3008 Tray 2	C7058-67905	C4096A
2200	RG5-5559	N/A	RB2-2900 Tray 1 RB2-2891 Tray 2/3, RB2-6304 500 Sheet Tray	RG5-4128 Tray 1 C7058-67903 Tray 2	RG5-5581	RF5-3272 Tray 1, RB2-6474 500 Sheet Tray RB2-3008 250 Sheet Tray	C7058-67905	C4096A
2300	RM1-0354	U6180-60001	RC1-0945 Tray 1 RB2-6304 500 Sheet Tray RB2-3484 Tray 3	RM1-0332	RM1-0338	RC1-0939 Tray 1 RC1-0954 Tray 2 RB2-9960 Tray 3	RM1-0370	Q2610A
2500	RG5-6903	N/A	RB3-0160 Tray 1 RB3-0161 Tray 2/3	RG5-6952 Tray 1	RF5-4040	RF5-4012 Tray 1 RB2-9960 Tray 2	N/A	C9700A C9703A
3100/3150	RG5-4675	H3975-60001	RB2-1634 RG5-4772 Document Scanner	RG5-3486	RF5-1534	RY7-5055 Document Scanner RY7-5008 Sub Pad Kit	RG5-3474	C3906A
3200	RG5-4589	H3965-60001	RB2-4026	N/A	RG5-4657	RF5-2886 Separation RY7-5050 Sub Pad Kit HB1-3035 Document Scanner	RG5-4593	C4092A
3300	RG9-1493	N/A	RFO-1008	RG0-1120	RG9-1483	RFO-1014	RG0-1010	C7115X
4	RG5-0454	C2001-69012	RB1-2127 MP Tray RB1-2126 Tray 2 RB1-2632 500 Sheet	RG5-0451	RF5-0349	RF5-0343	RG5-0886	92298A
4+ / 5	RG5-0879	C2037-69010 HP 4+ C3916-69001 HP 5	RB1-3477 Tray 2 HP 4+ RB1-7911 Tray 2 HP 5 RB1-2650 500 Sheet HP 4+ RB1-7983 500 Sheet HP 5	RG5-0877 HP 4+ RG5-2195 HP 5	RF5-0349	RF5-0343	RG5-0886 HP 4+ RG5-2189 HP 5	92298A
4000/4050	RG5-2661	C4118-67902	RG5-3718 Tray 1 RF5-1885 Feed Roller RB1-8865 D Roller	RG5-2655 Tray 1 RF5-2484 D Rollers	RG5-4283	RG5-5281	RG5-2648	C4127X
4100	RG5-5063	C8057-67901	RG5-3718 Tray 1 RF5-3114 Feed Roller RB1-8857 D Roller	RG5-5084 Tray 1 RG5-5277 Tray 2	RG5-5295	RG5-5281	RG5-5094	C8061X

QUICK REFERENCE GUIDE

12/9/2003



Model	Fuser	Maintenance Kits	Pickup roller	Pickup Assembly	Transfer Roller	Separation Pad	Delivery Assembly	Toner C.
4200	RM1-0013	Q2429-69001	RL1-0019 Tray 1 RM1-0036 Tray 2/3 RM1-0037 Tray 2/3 Feed	RM1-0004 Tray 1	RM1-0699	RL1-0007 Tray 1	RM1-0026	Q1338A
4300	RM1-0101	Q2436-69001	RL1-0019 Tray 1 RM1-0036 Tray 2/3 RM1-0037 Tray 2/3 Feed	RM1-0004 Tray 1	RM1-0699	RL1-0007 Tray 1	RM1-0026	Q1339A
4500	RG5-5154	C4197A	RB2-0717 Tray 1 RF5-1885 Feed/Separation RB1-8865 D Roller	N/A	RF5-2112	RB2-0734 MP Tray	RG5-5135	C4191A - C4194A
4600	RG6-6493	C9752A	RG9-1529 Tray 1 RF5-3739 Tray 2/3	RG5-6468	C9724A KIT	RF5-3750 Tray 1	N/A	C9720A - C9723A
5000	RG5-5455	C4110-69006	RB2-1820 MP Tray RB2-1821 Tray 2 RF5-2634 Tray 3	RG5-3519 Tray 1 RG5-3521 Tray 2	RG5-3579	RF5-2400/3439 MP Tray RF5-2435/RG9-1485 Tray 2	RG5-3542	C4129X
5100	RG5-7060	Q1860-67902	RB2-1820 Tray 1 RB1-1821 Tray 2 RB1-8865 D Roller	RG5-3519 Tray 1 RG5-3521 Tray 2	RG9-1542	RF5-4119 Tray 1 RF5-4120 Tray 2	RG5-3542	C4129X
5500	RG5-6848	N/A	RG9-1529 MP Tray RF5-3338 Feed/Separation RF5-3340 Pickup Roller RY7-5097 Roller Kit	RG5-6670	N/A	RF5-3865 MP Tray	N/A	C9730A - C9733A
5SI/8000	RG5-4447	C3971-67901	RB1-6730 Tray 1 RF5-1834 Feed/Separation RF5-1835 Pickup Roller	RG5-1880 Tray 1 RG5-1852 Tray 2/3	RF5-1412	RF5-1455 Tray 1	RG5-1874	C3909A
8100	RG5-4318	C3914-69001	RB1-9526 Tray 1 RF5-1834 Tray 2/3 RF5-2708 Pickup Roller	RG5-4330 Tray 1 RG5-4334 Tray 2/3	RF9-1394	RF5-2703 Tray 1	RG5-1874	C4182X
8500	RG5-3060	C4155A KIT	RB1-9526 Tray 1 RF5-1834 Feed/Separation RF5-1835 Pickup Roller	RG5-3054 Tray 1 RG5-3132	C4154A KIT	N/A	RG0-0110	C4149A - C4152A
9000	RG5-5750	C9152-67901	RF5-3340 RF5-3338 Feed/Separation	RG5-5677	RG5-5662	N/A	RG5-5643	C8543X